

cleanBox

cleanBox

GIORIK

INNOVATIVE COOKING EQUIPMENT SINCE 1963



cleanBox

GIORIK

INNOVATIVE COOKING EQUIPMENT SINCE 1963

Giorik SpA
Via Cavalieri di Vittorio Veneto, 14
32036 Sedico (BL) | ITALY

tel. +39.0437.807200 | fax +39.0437.807001
e-mail: info@giorik.com

www.giorik.com



OFFICIAL
CLEANING PARTNER



TIEFFE Chemical Solving
Via Artigianale, 29
25010 Montirone (BS) | ITALY

tel. +39.030 267443
e-mail: info@tf-pulire.it

www.tf-pulire.it

Use only the product illustrated in this catalog for the cleaning and maintenance of the Giorik ovens. These products will ensure an efficient cleaning and a long lasting oven life.

At the end of a working day, ovens must be cleaned to meet with hygienical standards and reduce wear and tear due to the potential corrosive substances left after the food cooking process.

To avoid the use of improper products that can be either too weak or too strong (becoming a potential risk for the oven integrity) Giorik developed a range of cleaning products for the ordinary and extraordinary maintenance of its ovens.
Four products for all professional oven needs.



OVENS WITHOUT SELF-WASHING SYSTEM

MANUAL OVEN CLEANER

High viscosity, fast-acting decarbonizer. Developed to be on cold or warm surfaces (max. 100°C) inside the oven cavity. Do not use on aluminum.



5/10 Kg



SOME TIPS ABOUT THE OVEN CLEANING

- Wait until the cooking chamber is less 100 C°.
- Do not use high or low-pressure water jet to clean the appliance.
- Do not use sponges or abrasive cloths or objects such as scrapers to remove deposits.
- Remove all trays before start cleaning.
- Manually remove removable residues, and put the extractable parts in the dishwasher.
- For manual cleaning of the oven, use only MANUAL OVEN CLEANER.
- At the end of a manual washing, rinse all surfaces ensuring that all detergent traces are removed.
- For self-washing system use only: SOLID SENSITIVE TAB, OVEN LIQUID DEGREASER to clean the cavity and OVEN DESCALER & RINSE to rinse it.
- For the boiler cleaning use only OVEN DESCALER & RINSE
- To clean the external parts of the oven use a damp cloth with a mild detergent

OVENS WITH SELF-WASHING SYSTEM



SOLID SENSITIVE TAB

Soluble powder tablets for strong oven degreasing and sanitizing cycle.



120 pz
65 g

OVEN LIQUID DEGREASER

Professional, concentrated detergent. It removes dirt in a single operation, thanks to its high effectiveness respecting stainless steel surfaces, welds and the other oven internal components.



5/10 Kg

OVEN DESCALER & RINSE



Ecological organic cleaner designed for the boiler descaling and for the rinsing cycle. (Only ovens equipped with rinsing system).



5/10 Kg