



T I E F F E
CHEMICAL SOLVING

DISH & GLASS

PROFESSIONAL DETERGENT FOR DISHWASHERS AND GLASSWASHERS

DISH & GLASS is a chlorinated alkaline liquid product, especially developed for automated washers of dishes, cups, glasses, glassware, etc.

This formula is made of caustic agents, softeners of water hardness, a high content of chlorinated agents and sequestering agents that facilitate rinsing, giving excellent cleaning and brilliance results on glassware and cutlery.

DISH & GLASS has a sanitizing action and removes effectively resistant stains, such as those of coffee and tea.

INSTRUCTION FOR USE

- It is normally used at a concentration of 0,2% - 0,8%, dosage with specific peristaltic pumps.
- Temperature between 55°C and 60°C with a minimum contact time of 30 seconds.
- Check regularly that the nozzles of the glass washers are not clogged. Also descale periodically the dishwashers with a descaling product. We suggest using our REMO KAL HW.

DOSAGE

According to the hardness of the water in °F (French degrees)

Soft (0-15)	2-4 g/l
Medium (15-25)	4-6 g/l
Hard (more than 25)	6-8 g/l

PRECAUTIONS

Consult the safety data sheet.

Emissione: MC 12/18